

Schöppe7 - 2021 - InputPatch

CH.Name	Patch	PanMode	Type	Location	Comments
K.In	1	MONO	Beta91	USL	
K.Out	2	MONO	D6	USL	
Sn.Top	3	MONO	e904	USL	
Sn.Bot	4	MONO	e904	USL	
HiHat	5	MONO	KM184	USL	
T1	6	MONO	e904	USL	
T2	7	MONO	e904	USL	
Fl.Tom	8	MONO	e904	USL	
OH.L	9	STEREO	KM184	USL	
OH.R	10	STEREO	KM184	USL	
Bass	11	MONO	XLR-Out	DSL	
Guit.Elec	12	MONO	BSS AR-133	DSCL	
Guit.Acc.	13	MONO	BSS AR-133	DSCL	
Violin	14	MONO	XLR-Out	DSC	
Accordeon	15	MONO	XLR-Out	DSR	
//SPARE	16	NONO			
Piano.L	17	STEREO	BSS AR-133	DSR	Optional
Piano.R	18	STEREO	BSS AR-133	DSR	Optional
Flute	19	MONO	XLR-Out	DSCR	
Brass1 - Titi	20	MONO	XLR-Out	USR or StageBox	Fiddly HF-Sytems // might end up being cable Mics
Brass2 - Marc	21	MONO	XLR-Out	USR or StageBox	Fiddly HF-Sytems // might end up being cable Mics
Brass3 - Pier	22	MONO	XLR-Out	USR or StageBox	Fiddly HF-Sytems // might end up being cable Mics
Perc.L	23	STEREO	KM184	USC	
Perc.R	24	STEREO	KM184	USC	
Vox.L	25	MONO	KMS104	DSR	Optional
Vox.C	26	MONO	KMS105	DSC	
Vox.R	27	MONO	KMS104	DSL	
TB	28	5.2.4	RoyerM1 / Neumann M49	FoH	only as input if desk doesn't have a TB-Bus
Ambi.L	29	STEREO	Whatever	DSR	
Ambi.R	30	STEREO	Whatever	DSL	
Audio FoH.L	31	STEREO		FoH	used for intro
Audio FoH.R	32	STEREO		FoH	used for intro

Schöppe7 - 2021 - OutPatch

BusName	Patch			Location	Comments
Isa.Mon	1	Accordeon	Mono // HF	StageBox	
Davina.Mon	2	Flute	Mono // HF	StageBox	
JoJo.Mon	3	Violin / MainVox	Mono // XLR at PedalBoard	DSC	
Lio.Mon	4	Guit / BackingVox	Mono // XLR at PedalBoard	DSC	
Werner.Mon	5	Bass	Mono // HF	StageBox	cute stick-thingy, can be inserted directly to stagebox' output
Chris.Mon	6	Drums	Mono // HardWired	USL	
Marc+Titi.Mon	7	Brass 1 + 2	Mono // HF	StageBox	
Pier.Mon	8	Brass 3	Mono // HF	StageBox	
FX1		Perc Plate	Stereo		
FX2		Warm Hall	Stereo		
FX3		Vocal RVB	Stereo		
FX4		DLY	Stereo		
MTX1	13	PA.L		StageBox	
MTX2	14	PA.R		StageBox	
MTX3	15	SUB		StageBox	
MTX4	16	NEAR		StageBox	